



SolarTech Power Solutions

Power supply dedicated battery cabinet installation



Overview

How do I connect a battery cabinet to a power system?

Procedure 1. Furnished with the battery cabinet are battery disconnect circuit breaker alarm lead assemblies. Refer to the power system installation manual to use these alarm leads to connect the battery cabinet battery disconnect circuit breaker alarm into the power system alarm circuits.

How do I install a VDC battery cabinet?

Set first battery in cabinet and attach the long lead (fast-on connector side marked positive) from the cabinet to the fast-on terminal on the positive terminal of the battery. See Figure 24. Facing left Facing right Facing left Vertiv™ NetSure™ 211 SERIES -48 VDC Battery Cabinet Installation & User Manual (Section 6023) Rev. L 23 Figure 24:.

How do you put a 4th Battery in a cabinet?

Place another inner battery spacer next to the third battery. 9. Set fourth battery in cabinet (being careful of the door fastener tabs hanging down) and attach the other end of the fast-on lugged cable to the negative terminal on the third battery (fast-on terminal).

How many battery cabinets can be connected together?

The battery cabinet is designed to be daisy-chained together with additional battery cabinets. There is no limit to the number of battery cabinets that can be connected together. However, a maximum system current of 30 A should be maintained regardless of the number of interconnected battery cabinets. Procedure NOTE! Refer to Figure 7.

How do you attach a battery cabinet to a relay rack?

Secure the battery cabinet to the relay rack with the provided 12-24 x 1/2" hex head thread-forming screws (six per side) (P/N 218710500) and #12 ground washers (three per side) (P/N 2156406 00). Torque these connections

to 35.0 in-lbs. Wall Method **WARNING!**.

How do I install a battery retention strap?

Install battery retention strap through openings in rear of cabinet. Orient the buckle per Figure 28. 3. Secure the battery cabinet to the relay rack with the provided 12-24 x 1/2" hex head thread-forming screws (six per side) (P/N 218710500) and #12 ground washers (three per side) (P/N 2156406 00). Torque these connections to 35.0 in-lbs.

Power supply dedicated battery cabinet installation

Contact Us

For catalog requests, pricing, or partnerships, please visit:
<https://zegrzynek.pl>